

Peppermint Bark

- Melt one 11.5 oz bag of milk chocolate chips in a microwave.
About 60 seconds; stirring after about 30 seconds. Add 1 teaspoon of peppermint extract and mix well.
- Spread evenly on parchment paper covering a cookie sheet (it probably wont cover the whole pan, which is fine). Let sit in the refrigerator about 10 minutes
- Melt 11.5 oz white chocolate in microwave (also stirring halfway through the melting time) & spread evenly over top of milk chocolate.
- Top with crushed peppermint and refrigerate until firm.
 - Break a part in pieces & serve